



“To know I can check and see how the store is doing even without being there is very helpful.”

Reveille Joe Coffee, Coffee Shop

Questions?

Call us at 1-877-270-3475

or

Log in to Silver Back Office to chat with a representative

Visit NCRSilver.com



Both NCR Silver

NCR Silver Pro

Browse by categories


Welcome

NCR Silver

NCR Silver Pro Restaurant

Edition

Receipt Printer Model 350 Wireless Connection Setup



Multiple Bluetooth printers can be connected to one POS device using Bluetooth. However, due to the nature of Bluetooth, multiple POS devices cannot be connected to the same Bluetooth printer.



Follow the instructions below to set up your countertop receipt printer (Model 350) using a wireless (Bluetooth) connection. However, if you have more than one iOS device that needs to print to a kitchen/receipt printer and the printer is far away from your router, you can use a [NetGear wireless bridge](#) or an [Apple AirPort Express](#).

POS Device Setup

1. Open the **Settings** app on your POS device and tap **Bluetooth**.
2. Make sure that **Bluetooth** is **On**.

3. Look for the printer name **SRP-35IIOBE** and tap it.
4. Enter the PIN and tap **Pair**. The PIN is 0000 (four zeros).
5. Open the POS app and log in.

POS App Setup

1. Tap the **Home** icon to get to the app's **Home** screen and tap .
 2. Tap **Configure printers**.
 3. If you see the "**Printer found!**" message, tap **Yes** and skip to step 6. If not, continue with step 4.
 4. Tap **Find new printer**.
 5. Tap **Bluetooth**.
 6. Enter a name for the printer that is something meaningful to you, such as the area of the store where the printer is located.
 7. Choose your printer's role. Two types of printers are available to use with the POS app:
 - **Receipt Printer** — is a receipt printer used to print customer receipts and to provide a means for signature capture if you do not have digital on-screen capture set up.
 - **Kitchen Printer** — is used to print a kitchen "chit". A chit contains instructions to the kitchen or other prep area on how to prepare an item. Kitchen chits do not look just like regular receipts — they display the item name and how to prepare it (via modifiers), but they do not include any price information.

If you only have one printer, it can be used as both a receipt printer and a kitchen printer.
 8. Toggle the **Cash drawer attached** button **On** if you are using a cash drawer with this receipt printer. This will open the cash drawer automatically. Tap **Done**.
 9. Set the printer to Default to have your device automatically print to this printer.
 10. Tap **OK** on the **Success** popup.
 11. Tap the blue arrow for your printer.
 12. Tap **Print test receipt**.
 13. Tap **Done** and then **Close** to close the **Printers** screen.

Keywords: printers, receipt printers, printer configuration, wireless connectivity, print receipts, kitchen printers

configure printer, pos setup, hardware

©2013 NCR Corporation. All Rights Reserved.

