DEVICE REPAIR TECHNICAL TERMS

10.2016

CELLAIRIS

Take a look Rear Facing Camera (not Front Facing Camera Power Button at the shown) iPhone 5 Mute Switch for the Volume Buttons Front Glass basic Digitizer Apple LCD Device Home Button Lavout Charge Port

CELLPHONE SCREEN REPLACEMENT TECHNICAL TERM

A cellphone screen "assembly" contains all of the following components:

- Glass
- UV Glue
- Digitizer (Digi)
- Liquid Crystal Display (LCD)



IPHONE AND IPAD MODULAR REPAIRS

- Wi-Fi Antenna Flex Cable Antenna that connects to WiFi and Bluetooth
- Power Button Flex Cable Flex cable that controls the power button
- Volume and Mute Switch Flex Cable Flex cables that controls the volume/mute buttons
- Proximity Sensor and Front Facing Camera Cable
 - Proximity sensor turns the screen off during phone calls so the user's ear or cheek don't press buttons on the touchscreen by accident during a call
 - Front facing camera faces the user
- Back Camera Rear camera that faces away from the user
- Charge Port Plug for the charging/data cable



IPHONE AND IPAD MODULAR REPAIRS

- Ear Speaker Speaker that is activated during phone conversations
- External Speaker Speaker that plays music, videos, and ring tones
- Battery Stores charge and powers the phone
- Home Button Flex Turns the click of the home button into a signal that is sent to the motherboard



